

D-Link Router : Firmware 3

This setting applies to D-Link 520B, 2542T router.

Step 1:


- : Open Internet Explorer and type **192.168.1.1**(default) into the address bar. (refer router quick guide manual)
- : Fill in Username & Password.(default: **admin**, password **admin**)
- : Click "**OK**" to login.



Step 2:

- With this new firmware, we should create a internet connection first before we begin configure the port forwarding.
- : Click "**Quick Setup**" on the left.
 - : Uncheck the "**DSL Auto-connect** " to enable manual configuration.

: After clicked the **Save/Apply** button, a small windows will prompt out as shown below, just click "**OK**" to proceed.



Step 5:

: Select "**Management**" > "**Save/Reboot**" on your left.

: Click on "**Save/Reboot**" button to Save the settings.

